

# EVERY DROP IS PRECIOUS

"designed to save you money  
by saving water & energy"

## HAIR WASH PACK FITTING GUIDE TO A SHOWER UNIT, BATH/SHOWER MIXER OR KITCHEN/UTILITY TAP

### **N.B: Not suitable for use with electric or pumped showers.**

Thank you for purchasing the Hair Wash pack, we hope you will be delighted with it. Please see [www.everydropisprecious.com](http://www.everydropisprecious.com) to see our full range of water & energy saving packs and products for your home, pets, garden and business, along with useful tips and info, to help further reduce your water & energy bills.

These fitting guidelines have been prepared to help you but you must exercise due care and attention at all times. We do not accept any responsibility for damage / problems that may occur through improper fitting or use.

### **ABOUT THIS PRODUCT:**

The Hair Wash pack has been designed for easy, less mess hair washing. Once installed and the tap(s) is turned on, you simply push the lever for water to flow, and release to stop the flow. It ensures water isn't needlessly wasted whilst you are busy shampooing / rinsing and means you don't have to turn the taps off every time you put the hose down to avoid being soaked! Also, as we at Every Drop Is Precious have discovered, it's great for washing pets and can be used in caravans, motorhomes or boats too!

### **PARTS AND CONTENTS INCLUDED IN PACK:**



### **PREPARATION:**

Remove all parts from their packaging and inspect for any transport damage prior to fitting. Turn off your taps before fitting.

### **CLEANING:**

Clean with a damp cloth to remove any scum/lime scale build up. Please do not use abrasive chemicals as they may cause damage.

### **WARRANTY:**

The Hair Wash pack is under warranty for 2 years against any manufacturing defects. In the unlikely event that your Hair Wash should be broken / faulty within the 2 year warranty period through no fault of your own, please contact us directly.

### **STEP 1 OF 3**

Simply unscrew your existing shower hose from its connection.



### **STEP 2 OF 3**

Screw new hose to the shower or bath/shower mixer fitting (regulator end):



### **STEP 3 OF 3**

Attach the Hair Wash Shower Head to the other end of the hose:



**TO USE:** Simply turn on the bath taps or shower and push the lever on the Hair Wash Shower Head to operate. You can adjust the water flow by using less pressure on the lever (if you find the pressure is too strong, then only turn the taps on half way). When you have finished using the Hair Wash, **remember to turn off the taps!**

### **TO USE ON A KITCHEN / UTILITY TAP (24MM):**

Unscrew existing regulator on kitchen tap and screw on the Adaptor to the kitchen tap (male black rubber adaptor included to allow for a female tap thread). Screw the hose (at regulator end) to the Adaptor and simply screw the Hair Wash Shower Head to the other end of hose. Operate as above.

**WARNING: IT IS IMPORTANT TO ALWAYS TURN OFF THE WATER AFTER USE, TO AVOID BURSTING THE HOSE. THE HAIR WASH SHOWER HEAD CANNOT BE USED AS A PERMANENT WATER STOP, AND HAS ONLY BEEN DESIGNED TO GIVE A TEMPORARY SHUT OFF.**